

Thank you for purchasing your new SOLO WERKS S1 Coilover suspension.

IMPORTANT

**DO NOT USE POWERTOOLS ON SHOCK SHAFTS WHEN INSTALLING -
WARRANTY WILL BE VOID.**

USE ALLEN KEYS ON ALL SHOCK SHAFTS WHEN INSTALLING

SOLO WERKS recommends that you have this kit installed by a qualified professional. Solo Werks or its authorized agents are not responsible for damage or failure resulting from an improper or modified installation.

All suspension-related components must be inspected and in good working condition. You should inspect all bushings, tie rods, hubs, bearings, strut mounts, sway bar end links, wheels, tires, etc. and replace them if necessary.

This suspension system was designed to work best with the factory wheel/tire combination. Any deviations from these specifications could result in significantly altered handling characteristics and/or increased interference risk to other vehicle components.

SOLO WERKS TIP: *Depending on the offset & size your wheels/tires, wheel spacers may be required for proper fitment.*

If suspension is lowered past the recommended measurements there can be possible interference with multiple vehicle components; (i.e. modification may be necessary to fender lips, seams etc...). This will also void your Solo Werks warranty.

After installing the suspension system, a four-wheel alignment must be performed according to manufacturer's specifications. Check and reset load- dependent brake compensator, ABS system and headlight aim according to manufacturer's specifications (If applicable).

ALL RUBBER- MOUNTED STRUT/ DAMPER ATTACHMENTS MUST NOT BE FULLY TIGHTENED UNTIL **AFTER THE SUSPENSION SYSTEM IS LOADED** (WHEELS ON THE GROUND). OTHER MOUNTING FASTENERS (FOR EXAMPLE BRACKETS) MUST BE SECURELY TIGHTENED BEFORE LOAD IS PLACED ON THE SUSPENSION SYSTEM

Every effort has been made to avoid printing errors in our literature. However, if there are any application or specification errors or omissions we must disclaim responsibility.

Original Suspension Removal- Front:


SOLO WERKS TIP: *Disconnect Headlight level sensor on control arm (if equipped) before any other steps are taken. Disregard for this step could result in damage to sensor link.*

1. Support Lower Control Arm/Spindle with floor jack.
2. Remove any lines from original suspension strut mounts.
3. Remove OEM sway bar end link from strut housing.
4. Disconnect tie rod end from the steering knuckle.
5. Disconnect upper control arms from steering knuckle.
6. Remove three upper strut housing bolts that attach the strut to the chassis.
7. Remove Lower strut bolt/nut from the lower control arm.
8. While pushing down on the suspension you will now be able to remove the OEM strut as an assembly – strut housing, spring, upper strut mount, upper control arms.

NOTE: If you are using your existing upper strut mount and control arms you must remove these items from the strut assembly. These items are under extreme pressure from the front spring and must be removed using an appropriate spring compressor to relieve the pressure. Follow the directions given by the manufacturer of the Spring Compressor to safely remove the spring and disassemble the Strut Assembly.


SOLO WERKS TIP: *OEM suspension components such as strut mounts bearings, control arms, etc. are a consumable/wear item and are a known fail point on this chassis. Solo Werks recommends using new mounts with new OEM Bearings and leaving your original suspension as an assembly. These parts are available from your Solo Werks Dealer or your local VW/Audi parts dealer.*

Complete Kit



No.	Description	Part No	Qty
1	Front Shock	800860	2
2	Rear Shock	800881/800880	2
3	Spanner Wrench	700006	2
4	Height Adjuster	700008	2
5	Rear Spring	801090/801310	2
7	Front Main Spring	800870	2
8	Helper Spring	800030	2

Solo Werks Coilover Pre Assembly – Priming the Dampers



SOLO WERKS TIP: *As the suspension is shipped and stored in a horizontal position, it is advisable to exercise or Prime the shock absorber before you install them to ensure that the internal contents are in the correct chambers. Therefore, we advise that before you assemble the coilover shock absorber, take a moment to purge the shock absorber.*

To do this, one side at a time remove the following from one of the Coilover Assemblies (if equipped):


- *Upper fasteners* (lock nut and securing nut – model dependent)*
- *Upper Spring Perch*
- *Main Spring*
- *Spring Isolator*
- *Helper Spring*

You will then be left with the coilover strut with the bumpstop and vent disc on the shaft. Pull the bumpstop up to the top of the chrome shock shaft, just before the threaded portion.

With the shock upright (as it would be installed in the vehicle) compress the shock shaft until the bump stop touches the shock housing and then pull to extend the shock shaft back to full extension.


Repeat 3-5 times minimum. You will notice the shock forces getting progressively harder each time. Once they feel consistent each way, you are ready to install.

Figure 1



N.o	Part No.	Description	Quantity
1	800860	Strut Housing Front Assembly	1
2		Shock Absorber Insert	1
3		Housing top Nut	1
4		Vent Disc	1
5	710013	Adjustable Spring Collar	1
6		Plastic Dust Boot	1
7		Bump Stop	1
8	800030	Helper Spring	1
9		Intermediate Ring	
10	800870	Spring 800870	
11		Nut	

Figure 2



N.o	Part No.	Description	Quantity
1	800881/800880	Rear Damper Assembly	1
2		Vent Disc	1
3		Plastic Dust Boot	1
4		Bump Stop	1
5		Nut	1
6	700008	Adjustable Spring Perch	1
7		Composite Isolator	1
8	801090/801310	Rear Spring	1

Solo Werks Coilover Assembly and Installation – Front:

1. **Work In the OEM Upper Bearings - Rotate the bearing a few times to break it in**
 - a. *We have found that brand new or even existing bearings can get stuck as they have a very limited rotation when installed*
 - b. *If they are stuck or too hard to move, they will not allow the assembly to rotate as it should and will create a spring bind that will produce a “boing” or “clang” sound of the springs recoiling*

Assemble the Coilover assembly with the OEM Strut Mount using the provided hardware as in the diagram Fig.1

**DO NOT USE POWERTOOLS ON SHOCK SHAFTS WHEN INSTALLING -
WARRANTY WILL BE VOID.**

USE ALLEN KEYS ON ALL SHOCK SHAFTS WHEN INSTALLING

- a. Top nut should be torqued to 44 ft-lbs. (Fig. 1 #11)
- b. Once assembled, we recommend starting the main perch at 25mm (1”) of thread remaining below the main perch/spring seat using the included spanner wrench – actual vehicle height will be set later in the process. (Fig.1 #1)

NOTE: Use of an anti-corrosion spray such as the Boeshield T-9 on the threads & main perch/spring seat at this point (Fig.1 #1) can make the adjustment process much easier and will add an extra layer of protection. Boeshield T-9 is available from your Solo Werks dealer.

2. Insert strut assembly into vehicle
 - a. Reinstall three upper strut mount bolts hand tight (snug) but do not torque at this time.
3. NOTE: Before proceeding with the next step, inspect the lower control arm mount is clean and free of debris (rust/dirt etc.) before installation of the new strut assembly.
4. Raise suspension and reinstall bottom of strut into suspension fork and insert pinch bolt and tighten, making sure the base of strut housing is completely seated inside suspension fork.
 - a. Do not torque at this time
5. Reinstall upper control arms into steering knuckle
6. Reinstall tie rod end into steering arm
7. Reconnect any lines/hoses or headlight sensors
8. Once vehicle is placed back on the ground under its own weight, Torque upper strut mount bolts to 50 ft-lbs and bottom strut pinch bolt to 66 ft-lbs.
9. Make sure all other attaching bolts are torqued properly
10. **HEIGHT ADJUSTABLE PERCH SET SCREW MAXIMUM TORQUE IS 1-2Nm or 0.74-1.47 ft-lbs**

Original Suspension Removal- Rear:

SOLO WERKS TIP: *Disconnect Headlight level sensor from lower control arm before any other steps are taken. Disregard for this step could result in damage to sensor link.*

1. While Supporting lower trailing arm in the compressed position (loaded as if it is on the ground)
 - a. Remove (2) fender liner clips to allow access to the upper shock mount bolts holding upper shock mount (Fig.2 #2)
 - b. Remove (2) upper shock mount bolts disconnecting upper shock mount from chassis
 - c. Remove lower shock bolt and remove shock from vehicle
NOTE: Retain OEM washer from lower shock mount to re-use during installation, taking note of orientation.
 - d. Slowly lower rear trailing arm to help remove the pressure on the rear springs
 - e. From the underside of control arm, clip the locating pin from the OEM lower spring pad.
 - f. Turn OEM spring shield away to create access to OEM spring.
 - g. Using a properly rated spring compressor, compress spring.
 - h. Disconnect Lower control arm/link from knuckle.
 - i. Remove spring
 - j. Make note of orientation of OEM shock mount to be reinstalled later.

Solo Werks Coilover Assembly and Installation – Rear:

The Rear of this platform is a combination of a rear lowering spring & adjustable spring perch and specially matched shock absorber. The shock absorber does not need to be adjusted in any way to change the ride height.

SOLO WORKS TIP: *Just like the front struts, it is advisable to Prime the rear shocks as well. To purge the rear shocks: Refer to procedure on page 4.*


In the vertical position (as it would be installed in the vehicle):

1. Extend the shock rod to its full extent
 2. Compress until 1" of the chrome shock rod is visible outside of the shock housing
 3. Repeat 3-5 times or until the strokes feel consistent.
-
1. Remove both upper and lower factory spring pads from the vehicle, and ensure that both areas are clean and free of any dirt or debris.
 2. The Solo-Werks rear spring perch will be installed on top of the spring
 - i. Install new spring onto adjustable spring perch (Fig.2 #8) WITH the Composite Isolator between the body and the perch (Fig.2 #7) and place into vehicle reusing lower OEM spring pad. (upper spring pad is discarded)

Solo Werks Tip: *On all models make sure the supplied Composite spring perch isolator is installed in-between the chassis and the adjustable spring perch. (Fig. 2 #7)*

3. Assemble Solo-Werks rear shock (Fig.2) reusing OEM upper shock mount. Torque shock shaft nut (Fig.2 #6) to 18 ft-lbs.
4. Place shock into vehicle and reinstall two upper shock mount bolts and torque to 26 ft-lbs.
5. Re install fender liner clips
6. Re install the lower bolt through the shock mount with OEM inner shock washer **between** the shock mount and knuckle.
 - a. Do not torque lower shock bolts until vehicle is back on the ground and all weight is on vehicle.
 - b. Torque lower shock bolts to 90 ft-lbs.
7. Make sure all attaching bolts are torqued properly
8. Adjust final height

Solo Werks Coilover Final Details – Heights & Working Ranges



		Lowering Range			
		in Mm		in Inch	
Model	Year	Front	Rear	Front	Rear
A4 B8 2wd / Quattro	08'-13'	25-75mm	25-75mm	1.0"-3.0"	1.0"-3.0"
A4 B8 S4	08'-13'	12-63mm	12-63mm	0.5"-2.5"	0.5"-2.5"

Front Measurement


Max low mm	Max low Inch	Max high mm	Max high Inch	OEM mm	OEM Inch
310	12 1/5"	360	14 1/4"	385	15"
310	12 1/5"	360	14 1/4"	370	14 1/2"

Rear Measurement

Max low mm	Max low Inch	Max high mm	Max high Inch	OEM mm	OEM Inch
315	12 1/2"	365	14 1/4"	390	15 1/4"
315	12 1/2"	365	14 1/4"	375	14 3/4"

- These measurements are in place to allow both front and rear dampers to operate properly and allow for ample shock travel.
- All measurements will be referenced from "center of wheel hub to bottom lip of fender" (see example figure "a")
- Using this system outside of this range can cause premature failure and is cause to void your manufacturer specified warranty.
- Helper springs are intended to keep preload on the main spring under full suspension extension, do not remove!

My Setup - Heights & Working Ranges



Use this page to record your setup heights for easy future reference

Front Measurement						
Date	Max low mm	Max low Inch	Max high mm	Max high Inch	OEM mm	OEM Inch
Solo Spec	310	12 1/4"	360	14 1/4"	385	15"

Rear Measurement						
Date	Max low mm	Max low Inch	Max high mm	Max high Inch	OEM mm	OEM Inch
Solo Spec	315	12 1/2"	365	14 1/4"	390	15 1/4"